

Emergency Door Release

Resettable & Break-Glass

Range: Exit Devices

A range of emergency door releases (EDR's) to provide a physical method of unlocking an electronic lock in the event of an emergency.

Emergency door releases (EDR's) are generally fitted where there is no manual method to permanently release an electronically locked door in the event of an emergency. These units are normally electrically connected in line (series) with "fail safe" locks, to remove power to the lock when the unit is activated - **it is strongly recommended that the local fire regulations are understood, and any products fitted to fire escape doors must comply with the local fire officers regulations.**

The EM201 is a double pole resettable EDR. Pressing on the front face will cause the plastic plate to drop and operate the micro switch. The plate will remain in the dropped position until the unit is reset by means of a key.

The EM200 is a double pole break-glass EDR. Pressing on the front plate will cause the plexi-glass to break, and this will operate the micro switch. The unit is reset by replacing the plexi-glass.

The MX-03 is an optional protective cover to prevent accidental activation of the EDR's.



EM200



EM201



MX-03

Technical specification

Colour	Green
Dimensions:	
EM200	86 x 86 x 50mm
EM201	86 x 86 x 50mm
Contact rating:	
Voltage	30VDC
Current	2 Amps

Product codes

EM200	Breakglass EDR
EM201	Resettable EDR
MX-03	Protective cover
EMKEY	Spare reset key for EM201 - Qty 10
EM200GDMGLASS	Replacement glass for EM200 - Qty 10