

TIMEGUARD®

Die Cast Oval Bulkhead – Bezels

Model: LEDBH020ELB Oval Eyelid Bezel

Model: LEDBH020GRB Oval Grill Bezel

Model: LEDBH010ELB Small Oval Eyelid Bezel

Model: LEDBH010GRB Small Oval Grill Bezel

Die Cast Rectangle Bulkhead – Bezels

Model: LEDBHRE20ELBH Rectangle Eyelid Bezel Horizontal

Model: LEDBHRE20ELBV Rectangle Eyelid Bezel Vertical

Model: LEDBHRE20GRB Rectangle Grill Bezel

Model: LEDBHRE10ELBH

Small Rectangle Eyelid Bezel – Horizontal

Model: LEDBHRE10ELBV

Small Rectangle Eyelid Bezel – Vertical

Model: LEDBHRE10GRB

Small Rectangle Grill Bezel

1. General Information

These instructions cover the installation of the bezel assembly to the LEDBH die cast bulkhead extension range. The installation of the bezel to each model is similar in arrangement. These instructions should be read carefully and retained for further reference and maintenance.

2. Safety

- Before installation or maintenance, ensure the mains supply to the luminaire is switched off and the circuit supply fuses are removed or the circuit breaker turned off.
- It is recommended that a qualified electrician is consulted or used for the installation of these products and install in accordance with the current IEE wiring and Building Regulations.

3. Technical Specifications

- CE Certified
- EC Directives: Conforms to latest directives

4. Tools Needed

Note: 4 Allen bolts are supplied with each of the bulkheads as standard (not included with the bezels).

- Pozi screwdriver
- Allen Key – If Allen bolts are used, refer to below table for Allen Key sizes.

| Bulkhead Model Numbers | Available Bezels | Allen Key Size |
|---|---|-----------------------|
| LEDBHO20W 20W LED Die Cast Oval | LEDBHO20ELB Oval Eyelid Bezel LEDBHO20GRB Oval Grill Bezel | 4mm |
| LEDBHO10W 10W LED Die Cast Small Oval | LEDBHO10ELB Small Oval Eyelid Bezel LEDBHO10GRB Small Oval Grill Bezel | 3mm |
| LEDBHRE20W 20W LED Die Cast Rectangle | LEDBHRE20ELBH Rectangle Eyelid Bezel – Horizontal LEDBHRE20ELBV Rectangle Eyelid Bezel – Vertical LEDBHRE20GRB Rectangle Grill Bezel | 4mm |
| LEDBHRE10W 10W LED Die Cast Small Rectangle | LEDBHRE10ELBH Small Rectangle Eyelid Bezel – Horizontal LEDBHRE10ELBV Small Rectangle Eyelid Bezel – Vertical LEDBHRE10GRB Small Rectangle Grill Bezel | 3mm |

5. Fitting the Bezel

- 5.1 Ensure that the mains supply to the circuit breaker is switched off and the circuit supply fuses are removed or the circuit breaker turned OFF.
- 5.2 Undo the 4 Pozi screws and remove the current bezel.
- 5.3 Ensure the lens and gasket is in place.
- 5.4 Position the new bezel into place and secure using the 4 Pozi screws previously removed, making sure not to overtighten.

3 Year Guarantee

In the unlikely event of this product becoming faulty due to defective material or manufacture within 3 years of the date of purchase, please return it to your supplier in the first year with proof of purchase and it will be replaced free of charge. For years 2 and 3 or any difficulty in the first year, telephone the helpline on 020 8450 0515.

Note: A proof of purchase is required in all cases. For all eligible replacements (where agreed by Timeguard) the customer is responsible for all shipping/postage charges outside of the UK. All shipping costs are to be paid in advance before a replacement is sent.

3



If you experience problems, do not immediately return the unit to the store. Telephone the Timeguard Customer Helpline;

HELPLINE

020 8450 0515

or email helpline@timeguard.com

Qualified Customer Support Co-ordinators will be on-line to assist in resolving your query.



A **theben** Group Company

For a product brochure please contact:

Timeguard Limited.

Victory Park, 400 Edgware Road,

London NW2 6ND

Sales Office: 020 8452 1112

or email csc@timeguard.com

www.timeguard.com