# SW-EXT10

10 Zone Expander

The **SW-EXT10** is a ten zone expander for the **SW-1070** panel range.

It comes as a PCB circuit board assembly that fits inside the **SW-1070's** housing. There is a boxed version (**SW-EXT10B**) for remote expansion.

- All 10 expander zones analysed for inertia sensors
- 2 fully programmable changeover relays
- LED indicator for each relay
- Switch to activate each relay manually
- Voltage: 10Vdc to 15Vdc
- Current: 80mA quiescent
        160mA (relays on)
- Temperature: -10 to +40°C
- Weight: 95g (**SW-EXT10**)
        460g (**SW-EXT10B**)
- Size: 125 x 72 x 15mm (**SW-EXT10**)
        236 x 166 x 42mm (**SW-EXT10B**)
- BS 8243 & PD6662
- EN 50131-1   Grade 2 Class II

SecureWave
868MHz Radio

www.hkcsecurity.com

Safe & Secure