



Fig. 1 PA2E
Double End Push Panic Button

- ❶ Screw the unit base to mounting surface.
- ❷ Connect your alarm circuit wires to the PA contacts. This will create the circuit. Once the button is pressed in the circuit will be broken.
- ❸ Attach your tamper wires to the tamper terminals. If the lid is removed the tamper will activate. Other terminals are spare.
- ❹ Carefully fit the lid to the central post on the base.
- ❺ Ensure no snagging occurs.
- ❻ Operation:- Push End button inwards. The microswitch will only operate when both buttons are pushed simultaneously.
- ❼ Reset :- by using the reset key (supplied)

	Model	PA2E
Grade 3 Class II	●	
Microswitch Activation	●	
Tactile Switch Tamper	●	
Metal Reset Key	●	
Spare Keys to Order	●	
5 Terminals	●	
End Knock-out	●	
Back Knock-out	●	
2 Side Knock-outs	●	
Finishes	Plastic	Brass St/Steel
	PA2EW	PA2EB PA2ES
Installation Instructions	●	
Dimensions	Length	Width Height
	80	62 28mm

Description:
Grade 3 Class II
Double End Push Panic Button.

Manufactured to **BS EN50131**

Materials:
ABS

Temperature Range:
-40°C to +50°C

Tampers:
Tactile Switch Tamper

Switching Current:
500mA Max DC

Voltage Range:
15v DC Max

Body Colours:
White, PA2EW Black (S/Steel Cover)
PA2ES, Grey if requested

Surface Finishes:
Plastic PA2EW, Brass PA2EB,
Stainless Steel. PA2ES

KNIGHT
FIRE & SECURITY PRODUCTS LTD
<mailto:info@knightfireandsecurity.com>

Unit 84 Seawall Road Ind. Estate
Cardiff UK CF24 5TH
Tel: 0 (00 44) 29 20 48 81 29
Fax: 0 (00 44) 29 20 48 91 32

Drawing No: **PA2E Range**
Panic Buttons
Drawn: *Chris Moorman*
Date: 21/02/10

All dimensions in mm
Do not scale



© [Knight Fire & Security Products Ltd](http://knightfireandsecurity.com)
All cases of TM Infringement will be pursued.